

METOX-BW90

Date of update: May 15, 2017

т

е

С

METOX-BW90 is a peroxide initiator, based on 2-butanone peroxide in phthalate plasticiser. In comparison with standard MEKP it presents less hydrogen peroxide and water, as well as more MEKP dimer.



METOX-BW90 can be applied for curing of unsaturated polyester resins (UPR), gelcoats and of A bisphenol based and novolac based vinyl ester resins in the presence of cobalt accelerator or in cobalt-amine system. Applying the second accelerating system the gel and cure time can be shorter. For a standard

orthophthalic resin, the initiator presents longer gel time as compared to a standard initiator METOX-50W. The initiator is recommended for the production requiring long gel time and during the summer period, when using standard MEKP causes too short gel time. In comparison with METOX-BW85 it presents shorter gel time.

The use of standard MEKP for curing may be insufficient due to foaming. This effect is caused by hydrogen peroxide. In METOX-BW90 its contents was lowered, giving reduction of foaming.

Product description	2-butanone peroxide in diisononyl phthalate	
Appearance	Clear, colorless solution	
Active oxygen	8,7÷9,1%	
Peroxides	33÷36%	
Water content	Approximately 1,0%	
Density at 20°C	1,017 ÷ 1,025 g/cm ³	
Solubility	Phthalates	
Slightly soluble in	Water	
SADT	60°C	
Recommended storage temperature	0 - 25°C	
Hazards	Oxidizing agent, decomposes rapidly under the influence of heat, mechanical impurities or by contact with reducing agents. Never mix hardener with accelerator.	

Recommended precautions and first aid measures - see Material Safety Data Sheet for the mixture.

Copolymerization process: resin (100g) - hardener (2g)				
Hardener	Gelling time	The highest temperature	Time to temperature peak	
	[min]	[°C]	[min]	
METOX-BW85	30-31	163,8-167,0	47-51	
METOX-50W	27-28	145,0-149,4	46-48	
METOX-50WR	26-28	143,4-150,2	45-49	

Data for the resin used: orthophthalic unsaturated polyester, thixotropic - preaccelerated, low styrene emission.

All product information and suggestions herein are provided in good faith and in a reliable manner. Oxytop does not guarantee as to the completeness of the information contained herein for purpose or fitness for a particular purpose. Oxytop does not guarantee that all possible use does not infringe any patent. The purchaser should determine the suitability of the product for a particular purpose, by preliminary tests.

This document supersedes all previously issued data sheets (TDS) for a specific product. It is allowed to transmit, distribute, copy this document only in its original form, with headers and footers. It is not allowed to place the document on the website.